

Powder Dispenser PD250

Precise and repeatable dosing of Powder Reagents

NEW



Highlights

- Determination of chlorine according to ISO 7393-2:2000 (free + total)
- 250 tests
- 5 years reagent shelf life (unopened vial)
- Easy handling
- Precise dosage

The PD250 is designed for easy and controlled dosage of DPD powder reagents. One click gives the exact amount of reagent required for a 10 ml sample. The PD 250 is the perfect alternative to the Powder Packs for those carrying out a number of tests, saving time while also reducing the amount of packaging waste.

The reagent is supplied in sealed glass vials, sufficient for up to 250 tests. The protective sealing enables a shelf life of up to 5 years although, once the vial has been opened, the contents should be used within 6 months. The vials can be changed quickly and easily. Furthermore, the dispenser can be thoroughly cleaned and the ergonomic design allows for comfort during operation.



Refill Packs

Article	Order code
VARIO Chlorine Free 10 ml 2 reagent vials	530140
VARIO Chlorine Total 10 ml 2 reagent vials	530150
VARIO Chlorine Free + Total 10 ml one reagent vial each	530 60



Delivery Content

PD 250 in carton
including 1 reagent vial and instruction manual.

Article	Order code
PD 250 Set 1 - Free Chlorine Content: 1 powder dispenser "Free Chlorine" 1 reagent vial "Free Chlorine" 1 instruction manual 1 protective sleeve (rubber)	4194900
PD 250 Set 2 - Total Chlorine Content: 1 powder dispenser "Total Chlorine" 1 reagent vial "Total Chlorine" 1 instruction manual 1 protective sleeve (rubber)	4194910